

Astra Linux x86-64 « 401-PC»



Astra Linux - Astra Linux Special Edition .10265-01 (8.1).

Astra Linux «»,
«», (,).
-, (live-cd,) .:

```
dd if=./< > of=/dev/hdc
```

PRESS SPACE TO DISABLE IT

```
( boot setup 'h')
boot setup 'c' .
drive number: 2, (autoboot in 5)
's'
. «» 'Del' , bios.
bios «» cd- 'Esc'
, .
, bios (IDE 1), 'Esc'.
boot setup - , 'm'
```