

Astra Linux x86-64 « 401-PC»



Astra Linux - . [Astra Linux Special Edition .10265-01 \(8.1\)](#) .

Astra Linux «», .

«» , (,).

-, (live-cd,) .:

```
dd if=./< > of=/dev/hdc
```

PRESS SPACE TO DISABLE IT

(boot setup 'h')

boot setup 'c' .

drive number: 2, (autoboot in 5)

's'

. «» 'Del' , bios.

bios «» cd- 'Esc'

, . .

, bios (IDE 1), 'Esc'.

boot setup - , 'm'