

Astra Linux Special Edition

-
- [Astra Linux](#)
- [Astra Linux](#)
- [Astra Linux](#)
-

[Astra Linux](#)



:

- Astra Linux Special Edition .10015-01 (1.6) 8 T8X x86 T10 x86
- Astra Linux Common Edition 2.12.43



Astra Linux

Astra Linux T8X x86 T10 x86 (-) Astra Linux (-) (-).

- Astra Linux Special Edition .10015-01 (1.6) [20210730SE16 \(8\)](#) ;
- Astra Linux Common Edition 2.12.43 .

MIG.

1. ISO- ISO- USB-.
2. ISO- . ISO- web- : <https://m-infogroup.ru/> (" ").
3. USB BIOS .
4. USB- 8.

1. USB- .
2. ISO- USB- Astra Linux:

```
sudo dd if=<_ISO-> of=/dev/<_>
```

Astra Linux

Astra Linux :

1. USB- ISO- .
2. USB.
3. () .
4. BIOS USB- (.):
 - a. Del.
 - b. BIOS:
 - i. Boot Devices.
 - ii. USB- ISO- .
 - iii. BIOS c c ("Save&Quit").
5. USB-:
 - a. .
 - b. () ("").
 - c. .
6. USB- .

Astra Linux

1. .
2. USB- ISO- .
3. USB-, :

```
sudo mount /dev/sdb1 /mnt
```

4. (, USB- /mnt). :
 - a. (Alt+T).
 - b. /mnt/MIG

```
cd /mnt/MIG
```

- c. :

```
sudo ./mig-t10-apt
```

- d. :

```
sudo ./mig-t10-env
```

5. USB- ISO- :

```
sudo umount /mnt
```

6. USB- ISO- .

Astra Linux

- . :
 1. .
 2. USB- ISO- .
 3. USB-, :

```
sudo mount /dev/sdb1 /mnt
```

4. (, USB- /mnt).
 - a. :

```
cd /mnt/MIG  
sudo ./mig-t10-profile <_>
```

- b. . , :

```
cd /mnt/MIG  
./mig-t10-profile.local
```

5. USB- ISO- :

```
sudo umount /mnt
```

6. USB- ISO- .

(, NetworkManager, . [Astra Linux](#)):

1. /etc/NetworkManager/<_>
:

```
password-flags=1
```

:

```
password=<>
```

,

```
password=gdata
```

2. :

```
• ;  
• ;
```

3. :

```
sudo system reboot
```