

USB-HID , hid-multitouch. - , .. , - ,

```
modprobe hid-multitouch
```

```
echo W X Y Z > /sys/module/hid_multitouch/drivers/hid\:hid-multitouch/new_id
```

```
:  
W - (. Isusb)  
X - vendor ID (. Isusb - ':)  
Y - device ID (. Isusb - ':)  
Z - , MT_CLS_* source/drivers/hid/hid-multitouch.c , Egalax
```

```
#define MT_CLS_EGALAX 0x0103
```

```
.: (1-7" 10").  
, , , /etc/rc.local exit .
```

[https://wiki.archlinux.org/index.php/Multitouch\\_displays](https://wiki.archlinux.org/index.php/Multitouch_displays)